



# Greasecutter Fast Foam GRILL CLEANER - DEGREASER

**Greasecutter Fast Foam** is a highly effective heavy duty grill cleaner & degreaser. This foam formulation clings to vertical surfaces rapidly removing even the most stubborn and carbonized grease. Its special formula used together with the foam trigger avoids aerosol emissions for a safe working environment.





**Greasecutter Fast Foam** does not generate hazardous fumes, reducing product flashback.

**Application area:** Grill, ovens, stove hoods, vents, broilers, fryers, and all the kitchen surfaces and utensils that need an effective degreasing action.

- **Clean** - Strips grease build-up.
- **Safe** - Free of hazardous fumes. No flashback.
- **Efficient** - Fast cleaning action.



## USE INSTRUCTIONS



- 1 Check hygiene plan and product label for detailed use information.
- 2 Wear protective gloves and goggles when using **Greasecutter Fast Foam**.
- 3 Turn off oven and grill or other appliances to be cleaned. The temperature should be lower than 70°C.
- 4 Spray **Greasecutter Fast Foam** on the surface to be cleaned.
- 5 Allow the product to penetrate grease deposits for 5 to 10 minutes.
- 6 Scrub stubborn soil if necessary. Wipe off dissolved and loosened grease with a damp cloth or paper.
- 7 Rinse surface with plenty of clean water.

## SPECIAL NOTES/ INFORMATION

Do not use on aluminium or painted surfaces. Test material compatibility in a small inconspicuous area before use.  
**For professional use only.**

## SAFETY INFORMATION

For further information and safety instructions, see product label and Safety Data Sheet.

## STORAGE CONDITIONS

Store between 5° and 35°C in original closed container only.

## PACK SIZE

4 x 750ml bottles with trigger foam sprayer